To Set Up the Star Press

First assemble the stand which consists of upper shelf, lower shelf four legs and two extensions (long) angle irons. Two of the legs have holes thru which the motor bracket support rod must nass and these should be assembled at the same narrower end of the stand. The two (long) extension angle irons should be attached outside the legs at top with the larger holes in the angle iron up - the press will be bolted to these angle

Mount the motor on the two brackets (twisted near one end), with the twisted ends to the left as you face the pulley end of the motor. Next, insert the motor bracket support rod (1) thru the hole in the bracket iron nearest the pulley, (2) thru the hole in the leg, (3) thru the other bracket iron, and (4) thru the other leg. Nuts locating pins on the top of the hold threaded support rod in place. chase bed, and also two locating


Bolt the press to the extension angle irons on the top of the stand so that the fly wheel will be on the same side as the motor pulley. The fly wheel can then be put on its shaft, with the set screw on the inside - for safety - when it is on the shaft. Line up the set Now put the V-belt in the groove in the flywheel, and by lifting the motor a little, the V-belt can be slipped into the groove in the motor pulley. Either the small (slow speed) pulley or the larger (faster) pulley will fit on the motor shaft. Southen the set screw on the flat part of the motor shaft to keep it

from slipping Bolt the ink table holder to the back of the chase bed, near the chase latch. You will notice that in addition to two bolts to fasten the holder in place there are two

holes in the holder to match, so that you will be sure to have it in the right position. Before placing it on the two pins, raise up the dog lever and have the dog lever roll (which is located at the end of the dog lever) on the cam of the roller car-

riage shaft. Novt insert the stem on the back of the ink table into the hole at the top of the ink table holder (above the chase

hed). Put the roller wheels (which you will find in a cloth bag tied onto



the press on the ends of the ink rollers and insert the ink rollers in place in the saddles or sockets on the machine.

The feed table arms bolt onto the front legs of the press, just below the front shaft, and the wooden feed table is mounted with wood screws on top of these arms. The illustration of the press in the catalog and the diagram (pr. 26) will be of help to you in assembling the

press. Make sure the press is well oiled.

The press is now ready to ope-

rate. Turn the flywheel around several times to make sure the press operates freely and properly before running it with the motor. The motor has been properly wired to have the flywheel turn counterclockwise or away from the opera-

Number of Leads To Pound
The following table gives the approximate number of leads of

approximate number of leads of a given size, per pound. It will be handy if you need a large quantity of one size, and wish to order

Free | Point |

For longer lengths use multiples of lengt

If couipped with his fountain the somation should be mounted on the same above and behind the ink table so that the upper composition of the sound o

Now that you have the press ready for operation, read the Printer's Guide over very carefully, which gives complete information on setting type, locking forms in

Note: When adjusting the impression on the Star Press, only the four screws in the corners of the platen are used

The table below shows the approximate number of words in a square inch of type of various sizes. It is accurate enough to be used in estimating the space any meaning will fill

| Number of version | Numb

The Printer's Guide, 9th Edition The Kelsey Company, Meriden, Conn. 06450